
Title: Set up a small network in packet tracer

Date: 08/13/2025


Author: Daysean Mensah

Add a router: Click on network devices bottom left






Routers:




• Drag and drop a router(eg 4331) into the white space

Add a switch: Click on network devices bottom left and click on switch



• Drag and drop a switch (eg: **2960**) into the whitespace:

Add a server: click on End Devices bottom left




• Drag and drop server(**Server-PT**) into the whitespace:

Add a PC: click on End Devices drag and drop PC into the white space



Connect: click on lighting bold bottom left: click on the black string cable



- Connect the **Router** to the **switch** using a copper straight-through cable. Select copper straight through cable again
 - Move your cursor into the white space and click on Router: & select
 GigabitEthernet0/0/0 & click on the switch select FastEthernet0/1
- Connect the **PC** to the **switch** using a copper straight-through cable. Select copper straight through cable again
 - Move your cursor into the white space and click on PC: & select FastEthernet0
 then click on switch and select FastEthernet0/2
- Connect the server to the switch using a copper straight-through cable
 - Move your cursor into the whitespace & click on the server.
 - Click on FastEthernet0 > then click on the switch select FastEthernet0/3

Click on the router > CLI

If you will see "Would you like to enter the initial configuration dialog". TYPE **no.** Then press enter

show ip interface brief

• Show interface status, ip etc

Bring GigabitEthernet0/0/0 interface up and assign an IP: G0/0/0 is shortcut

enable

configure terminal

interface GigabitEthernet0/0/0

no shutdown

(you will see router#)

(you will see Router (config)#)

(you will see Router (config-if)#)

(brings interface up)

• If you see log messages press enter

ip address 192.168.1.1 255.255.255.0

(assign the router an IP)

Configure a DHCP pool:

ip dhcp pool <POOL_NAME>

Example: ip dhcp pool LAN Pool

network < NETWORK ADDRESS > < SUBNET MASK >

Example: network 192.168.1.0 255.255.255.0

default-router < DEFAULT GATEWAY IP>

Example: default-router 192.168.1.1

dns-server <DNS SERVER IP1> <DNS SERVER IP2>

Example: dns-server 192.168.1.254

• 192.168.1.254 is the last IP in the dhcp pool

exit

show ip interface brief (verify ip address)

Before you save the configuration lets verify that the dhcp is working:

Click on the PC > IP config > click on DHCP

• Then you should see in IP address beginning with 192.168.1 & a DHCP request successful message

Now you can save the configuration: close the IP configuration click X > click on router Type: **write memory**

Final view

